

## **Maintenance Procedure for replacing the Lithium Battery**

### Lithium Battery Removal Procedure (Battery : 3V Lithium CR1220)

- **Step 1**



Slide a small flat head screwdriver under the battery.


- **Step 2**



Gently pivot the screwdriver downward so that it acts as a lever. Repeat this operation until you succeed to slide the battery out. Recycle the battery to the nearest battery deposit site.


## New Lithium Battery Installation Procedure

- **Step 1**



Gently lift the battery holder metallic retainer clip with a flathead screwdriver in order to make space for the new lithium battery.

- **Step 2**



While holding the clip open with the screw driver, slide the battery into place under the clip (with the positive + side facing up). Remove the screwdriver and gently push the new battery in the slot with your finger.